

## 49544 / MCX150S Low

---

Position	ItemNo	Description
01	49619	Side Glass
02	49606	Right Side Panel
03	49607	Left Side Panel
04	49065	Kick Plate
05	49066	Controller Front Panel
06	49067	Front Panel
07	49068	Back Panel
08	49648	Canopy
09	49070	Top Panel
10	49649	Base Deck
11	46693	Air Return Grid
12	49609	Shelf Bracket
13	49048	Shelf Bracket
14	45538	Shelf Bracket
15	49614	Shelf
16	49072	Shelf
17	46694	Shelf
18	46695	Price Holder
19	38562	Adjustable Foot
20	49632	Sliding Door Left
21	49633	Sliding Door Right
23	49624	Handle Base
24	49625	Handle
25	46514	Digital Controller XW60L
26	38590	LED Light 1200mm
27	46645	Evaporator
28	46625	Fan Motor
29	38625	Condenser
30	46610	Fan
31	46611	Fan Grid
32	46519	Fan Motor
33	46626	Filter Drier
34	48998	Compressor
35	46520	Condensate Tray Heater
36	46521	Water Evaporating Coil

2024-02-12

## 49544 / MCX150S Low

